

User Manual

SOL.Connect Center



Imprint:

Contact: Papendorf Software Engineering GmbH
Robert-Bosch-Str. 10
71116 Gärtringen, Deutschland
Phone: +49 (0)7034 27910 - 0
Fax: +49 (0)7034 27910 - 11

Email: www.papendorf-se.de
info@papendorf-se.de

Version: 1.2 - Date: 19.10.2007
Store user manual for future application!

Printed in Germany, ©2007 Papendorf Software Engineering GmbH
Copies and excerpts only with written permission of the publisher!
All rights, as well as modification in terms of advancement reserve!

Contents

Contents	3
1 About this manual	6
2 Safety instructions	7
3 Product description.....	8
3.1 System requirements.....	9
3.2 Specified normal application.....	10
3.3 Scope of delivery.....	10
3.4 Accessories.....	10
3.4.1 SOL.Connect MultiScan	10
3.4.1.1 Sensor Kits.....	11
3.4.2 SOL.Connect Power Manager.....	12
3.4.3 SOL.Connect Portal.....	12
3.4.4 Casing	13
3.4.5 Modem / network:	13
3.4.6 Network cable	13
4 Technical description	14
4.1 Data logger connections	14
4.1.1 Terminal strip (8-pole)	14
4.2 Large display connection	15
4.3 Signals and operational indicators on the device	16
4.3.1 LED display on top of the device	16
4.3.2 LED on the terminal strip.....	17
4.3.3 Audio signals	17
4.4 Compact Flash® memory card	17
5 Start-up.....	19
5.1 Connection via LAN-interface.....	19
5.1.1 Connection of LAN-cable.....	19
5.1.2 Network settings	19
5.1.2.1 Network router.....	21
5.1.2.2 Choosing connection	22
5.2 Using remote access (analogue/ISDN/GSM etc.)	22

5.3	Additional SOL.Connect devices	24
5.4	Connection Large Display.....	25
5.4.1	Connection serial Display (direct connection)	25
5.4.2	Connection of a remote display.....	25
5.5	Electrical mains connection	25
5.6	Switch-on.....	26
5.7	On-site verification of the installation	26
6	Mounting	27
7	Working with the data logger	29
7.1	User rights, access rights.....	29
7.2	Start page	30
7.2.1	Sub-menu editing functions	32
7.3	Plant state.....	32
7.4	Monitoring.....	34
7.4.1	Event notification (monitoring) editing functions	36
7.4.2	Email messages	38
7.4.3	Notification via alarm	39
7.5	Reports.....	39
7.5.1	Reports editing functions	42
7.5.2	Email messages	44
7.6	Configuration (Administrator domain).....	45
7.6.1	Core system	46
7.6.1.1	Network.....	46
7.6.1.2	Modem	48
7.6.1.3	Plant details.....	50
7.6.1.4	System time	52
7.6.1.5	System language options.....	55
7.6.2	Communication	55
7.6.2.1	Email service	55
7.6.2.2	Familiar free Email and online services	57
7.6.2.3	Message recipient.....	60
7.6.2.4	FTP-Upload.....	64
7.6.2.5	Display (optional)	66

7.6.3	Solar plant.....	67
7.6.3.1	General settings.....	67
7.6.3.2	Inverter	69
7.6.3.3	Sensors (optional)	71
7.6.3.4	In-/Outputs	74
7.6.3.5	Control station	76
7.6.3.6	Reimbursement.....	76
7.6.3.7	Administration of groups of inverter	78
7.6.3.8	Power Management (optional)	79
7.6.4	Security	80
7.6.4.1	Public access	80
7.6.4.2	Passwords	81
7.7	Download	82
7.7.1	Plant data.....	82
7.7.1	Documentation.....	84
8	XML-Upload via SOL.Connect Centers mpp	85
8.1	XML file structure	85
8.1.1	Section <description>	85
8.1.1.1	Description of column name (col_ref).....	86
8.1.1.2	Data type (data_type).....	87
8.1.2	Section <row>	87
8.2	XML file example	88
9	Disposal.....	89
10	Technical Data	90
11	Symbol definition.....	91
11.1	General	91
11.2	Status display.....	91
11.3	Notification	91
12	Declarations of Conformity.....	92
13	Image index	94

1 About this manual

This manual provides detailed product information and instructions on use of **SOL.Connect Centers**.

Due to the better legibility SOL.Connect Center will be identified as the **data logger**.

The SOL.Connect Center is offered in a standard edition or comes with optional SOL.Connect products for functional enhancements. Settings for these devices will be visible in the web interface if connected. Therefore the settings are labeled **optional** in the manual.

Important information in the manual is identified by means of various symbols shown below:



Attention!

The „**attention**“ symbol indicates an item whose disregard may result in damage to equipment and/or harm to persons. Information thus marked must be observed on all accounts.



Information!

The „**Information**“ symbol indicates supplementary information, the observance of which by the user leads to improved performance. Additional information for the user.

This document incorporates the latest version at the time of printing. It is subject to changes required by new functions and improvements.

The names of products and companies mentioned in this document may be protected trademarks.

2 Safety instructions

Readers of this manual are assumed to be familiar with regulations and guidelines concerning electrical installations and their connection to the mains power network. Particular attention must be paid to general safety regulations for working with electrical installations.

Please observe the safety instructions below to prevent injury to persons and damage to connected equipment.

Contact with electrically conductive parts can be life threatening even after their disconnection from the mains network. **Installation should only be performed in the de-energized state.**



Equipment must be installed only in protected/dry environments.



Do not use metallic/pointed/sharp instruments to access the housing's interior.



Prevent cables and terminals from being exposed.



The power connection must be furnished with a fuse and protective earth.



The power plug must be accessible at all times.



Qualified personnel only must perform maintenance.



Equipment must only be operated at the rated supply voltages (12-24 VDC, correct polarity). A suitable power supply unit is included in the scope of delivery.



Observe the manufacturer's instructions on handling of power supply units (especially switching units).



Observe the manufacturer's instructions on handling of inverters.

3 Product description

SOL.Connect Center (data logger) is a freely programmable system for acquiring, processing, evaluating and distributing system-related information and is a concept based on long years of experience. It is designed specially for monitoring processes at regenerative power plants. The system incorporates the following functions:

- Detailed query and storage as well as continuous evaluation of inverter data
- Monitoring of large plants of up to 500 inverters from different manufacturers is possible.
- Observation of yield/power/events (Monitoring)
- Individual management of inverter groups
- Issue of Email alarms on occurrence of incidents; issue of error messages (configurable)
- Internal preparation of reports and diagrams; automatic distribution via Email, HTTP (Internet)
- Display of current plant state (instantaneous values)
- Download of measurement data for further processing
- Dynamic language switchover for users

One decisive advantage of the SOL.Connect Center System is that the system's intelligence is within the SOL.Connect Center and therefore directly at the plant. This is what makes independent on-site monitoring possible.

The image below provides an overview of system components.




Image 3-1 Standard system overview

3.1 System requirements

For SOL.Connect Center following web browser are recommended:

Internet Explorer® from Version 6

Firefox® from Version 2

3.2 Specified normal application

The SOL.Connect Center is exclusively for the data reports and monitoring of the supporting inverter types. Information about inverter types is available from the manufacturer.

Any mechanical or physical modifications to the equipment – including the drilling of holes - will result in damage and invalidate all guarantee claims.

3.3 Scope of delivery

Data logger scope of delivery includes:

- SOL.Connect Center
- Terminator plug for RS485 inverter bus
- 1 GB Compact Flash[®] memory card (installed in the device) with pre-configured SOL.Connect Center software
- Plug-in power supply unit: Cable length: 1,5 m
 - Input: 90 ~ 264 VAC
 - Output: 12 V, 2 A, 75 x 43 x 34 mm (pre-mounted on the terminal strip)
- Crosslink Ethernet PC connection cable (2 m)
- Assembly kit: Assembly adapter, hat-rail clamp, screw set (3 screws and dowels) for fastening
- Manuals, connection scheme to SOL.Connect Center

3.4 Accessories

3.4.1 SOL.Connect MultiScan

AD-converter for integration of transducers, sensors, counters or transmitters.

The following sensors may be installed via the SOL.Connect MultiScan:

Irradiation sensor

- 0-150mV
- mono-/ polycrystalline or amorphous

- With or without temperature measurement

Module temperature sensor

- PT1000

Environment temperature sensor

- PT1000

Impulse generator

- Digital Input
- Passive 12 V...24 V

Transformer for power

0-20 mA output proportionally to the power

Attention!



The sensor module is only for use with the associated sensors. The functionality of other sensors cannot be guaranteed. Recommended sensors see chapter 3.4.1.1.

3.4.1.1 Sensor Kits

These sensors can be used for additional monitoring of the PV-plant. There are two variations available

	Sensor Kit „Light“	Sensor Kit „Pro“
irradiation-sensor	SI-SENSOR ^{®*} <ul style="list-style-type: none"> • Monocrystalline silicon • Case, protection mode: Powder-coated aluminium, IP65 • Linearity of the electronic circuit: $\pm 0,3\%$ from reading for 50 to 	ISET Sensor ^{®*} <ul style="list-style-type: none"> • Mono- / polycrystalline, amorphous (see sensor) • casing powder coated in facade quality, silver-grey • calibrated at the Institute für Solare Energieversorgung Kassel (ISET)

* excerpt of the manufacturer data

	Sensor Kit „Light“	Sensor Kit „Pro“
	1300 W/m ² • Accuracy at 25 °C: ± 1,5 °C • non-linearity: ± 0,5 °C Error at minimum and maximum temperature: ± 2,0 °C	• With integrated temperature measurement • measurement range : 0 to 1300 W/m ² • Accuracy : ± 4%* kristallin; ±5%* amorph
module temperature sensor	• PT 1000 • Platinum resistance wire • Aluminium adhesive tape 50 x 50 mm • 2-conductor connection • Operation temperature: -20° to +150° C • Accuracy : ± 0,5%*	
external temperature sensor	• PT 1000 • Platinum resistance • 2-terminals • Operation temperature: -50° to +80° • Accuracy : ± 0,5%*	

3.4.2 SOL.Connect Power Manager

The SOL.Connect® Power Manager allows a power limitation according to german EEG Novelle 2009 for generating plants over 100 kWp.

3.4.3 SOL.Connect Portal

Internet portal with public and private areas.

- Plant presentation
- Set up of graphical reports
- Publication and comparison of plant data
- Backup for log and configuration data
- Service interface for fitter, supplier and manufacturer.

* with a max. cable length of 3m

Information about additional accessories can be had from Papendorf Software Engineering GmbH under www.papendorf-se.de or via telephone.

3.4.4 Casing

- Protection class IP65 with separate casing for outdoor use

3.4.5 Modem / network:

- Analogue: DEVELO Microlink 56k i
- ISDN: DEVELO Microlink ISDN i
- GSM: Siemens MC35i Terminal
- WLAN: D-Link, Netgear

3.4.6 Network cable

- Commercially available RJ45 TP10/100 network cable

4 Technical description

4.1 Data logger connections

Data logger is equipped with the connections described below:



Image 4-1 SOL.Connect Center connections

- 1 Power supply terminal strip, EasyLan field bus (optional) , RS232 or RS485 data interface, 1x relay output for event message contact and 1x floating input
- 2 Serial interface for modem
- 3 3 LEDs for indicating operational statuses (red, yellow, green)
- 4 Dial-out (internet dial-in) and function switches (*function switch not yet assigned*)
- 5 RS485 data interface - RJ45 double socket for inverter connection
- 6 LAN Ethernet interface

i Function switch can be linked to the relay output, see chapter 7.6.3.4.

4.1.1 Terminal strip (8-pole)

	PIN	Function	Description
GND 12-24V-	GND	Voltage supply	
	12-24 V		
EasyLan GND	EasyLan	EasyLan bus	Field bus, e.g. for connecting a sensor module
	GND		
COM3 RS485 B A GND	-	(COM3) RS485 interface	Optional interface, e.g. for connecting a large display
	B		
	A		
	GND		
IN1 + IN1 -	IN1 +	Floating input	For connecting an error detector (switching voltage: 12 – 24 VDC). Link to relay output possible see 8.6.3.4
	IN1 -		
OK1+ OK1-	OK1 +	Relay output	For outputting error messages (max. switching voltage: 48 VDC)
	OK1 -		

4.2 Large display connection

The data logger supports displaying of system data (power, daily yield and total yield) on a large display (RS485), which is set to a HVG-based communication protocol. Since the HVG protocol is limited to a plant system power of <100 kW, a specially adapted HVG-based protocol can be selected if necessary.

The display can be connected directly to the data logger, or as remote display via a built-in serial-ethernet converter within the display.

The following string is sent to the display:

Value	Description
#	Start
00241479	Total yield = 00241479 kWh
001234	Daily yield = 001234 kWh
001234	Power (Pac) = 0012,34 kW

Value	Description
0000	Iac (not displayed)
0000	Upv (not displayed)
0000	Uac (not displayed)
4567	daily yield 2 = 4567 Wh (usually unused)
<CR><LF>	End (optional)
resulting String:	#002414790012340012340000000000004567

Characters in "red" will be added as extended HVG-protocol to support system power > 100 kW. However, it must also be provided by the display. According ballot must be taken with the display manufacturer, such as RiCo.

i The display must be operated in the same HVG mode as set in the data logger.

The extended HVG protocol can generally be used for equipment to 9999,99 kW of power if the display supports the extended HVG protocol.

i Guidelines for the network configuration of the Serial-Ethernet converter may be verified with an administrator!



More information can be found in the manual of the display and applied the serial-Ethernet converter.

4.3 Signals and operational indicators on the device

4.3.1 LED display on top of the device




1	2	3	4	5	6	7	8	1	= Stand-by, system operational
								1 bis 6	= Current power sum (1 min. – 6 max.)
								7	= Inverter event
								8	= General system event

The power sum of the LED display will be calculated on basis of the max. input value of the inverters (=100% per numbers of LED).

Since the so far indicated unit power is very low, it can come to increased display values at the beginning. In order to prevent this, the max. input power can be entered manually for each inverter (see chapter 7.6.3.2).

i In order to check the functioning of the LED display, all LEDs will light briefly on start-up.

4.3.2 LED on the terminal strip

 Data	Yellow on: Modem communications active
 Dial out	Red on: Modem can establish link independently (internet dial-in)
 Power	Green on: Power supply OK

i The "Dial Out" switch is used to enable / disable independent dial-out by SOL.Connect Center via modem → Dial-Out LED on. Active dial-out results in telecommunication charges for the operator

4.3.3 Audio signals

SOL.Connect Center emits an audio signal on start-up to acknowledge power-on. Other than that, an audio signal is only output on occurrence of an error, as on a PC.

4.4 Compact Flash[®] memory card

A Compact Flash[®] memory card is used as a storage medium by the data logger. The data logger does not function without an installed Compact Flash[®] memory card.



Attention!

The internally installed Compact Flash[®] memory card should only be changed by the manufacturer; otherwise any guarantee claims will be invalid. The system is not operable without a card.

5 Start-up

There are 2 possible ways to connect the SOL.Connect Center to the computer:


- Connection using a LAN-interface, with which a network setup must first be carried out where applicable. Please follow the step sequence carefully!
- remote access connection via **modem** dial-in.

In general, for the first use a "teach-in" for connected inverters or optionally connected devices (except SOL.Connect Power Manager) is required.

5.1 Connection via LAN-interface

5.1.1 Connection of LAN-cable

The application of the data logger is carried out exclusively using the LAN-interface:



Information!

The data logger should only be used in conjunction with the appropriate adapters and cables (e.g. commercially RJ45 TP10/100 network cables). This version needs a termination.

5.1.2 Network settings

If the data logger is to be integrated into a local area network (LAN), it first needs to be checked with a **network administrator** if the delivery status IP

address is already occupied in the same network. Should this be the case a new IP address has to be requested from the network administrator, and then has to be adapted via direct connection in the device and computer.

The delivery status IP address of the device is set to LAN IP address (see backside of device) **192.168.1.190** (network mask 255.255.255.0). Enter this IP address into a web browser and the data logger start will be page opened.



Image 5-1 IP (in delivery status) entry into web browser

Should the device have to be configured to another IP address, the network settings of the PC have to be aligned to those of the SOL.Connect Center in order to apply changes accordingly:

Informationn!



A note should be made of the previous settings of the PC in order to restore them!

- *Start* → *Control panel* → *Network connections* → right click on the *LAN (Local Area Connection)* connection and choose *Properties* → right click → properties)
- Select *Internet Protocol TCP/IP* → Press *Properties* button →




Image 5-2 LAN connection properties

- IP address: **192.168.1.191** (or the IP address allocated by the administrator)
Sub-network mask:
255.255.255.0
- Confirm your settings with "OK".




Image 5-3 TCP / IP connection properties

i Details of the configuration of the network settings must be observed and if necessary checked by an administrator (see chapter 7.6.1.1)!

Under network configuration (see chapter 7.6.1.1) enter the new IP address.

5.1.2.1 Network router

With use of a noetwork router certain ports must be released for several services:

Service	Port
NTP	123
FTP	20,21
SMTP	25
Control station mode	9009
HTTP	80



Please observe the user instruction of the relevant programme manufacturer!

5.1.2.2 Choosing connection

It is possible to choose between direct- and network connection (LAN):

Direct connection

Connection must be established using a **cross-link cable** to a LAN interface on the local computer.

Network connection (LAN)

The data logger must be connected to the available network using a **patch cable**.

After connection the IP address is entered into a web browser and the start page of the data logger will be opened. The address being used is the IP address of the unit 192.168.1.190 (as delivered) or the address integrated into the network (see Step 2).

5.2 Using remote access (analogue/ISDN/GSM etc.)

Operation of the data logger is carried out exclusively using the modem connection:



Modem connection (RS232, SUB-D9)

Image 5-2 Modem connection



Information!

Due to the large data volume the system gathers we recommend using a broadband connection with flat fee.

It is necessary to set up a connection to the telephone network between the computer and the data logger:

- Start → control panel → network connections → create new connection
- create connection with internet



Image 5-3 Connection with the internet



Image 5-4 Manual connection setup

- Set up connection manually
- Set up connection with modem
- Select modem

If only one modem has been installed, modem selection is unavailable.

- Enter „name“
- Enter „telephone number“
- Next → User name and password are not necessary!
- Finish creation of the connection
- The number can now be dialled



Image 5-5 Connection with DFÜ-Modem

If an ISDN modem is used in conjunction with a "normal" modem on the side of the data logger appropriate drivers need to be installed for "modem emulation".

In the case of AVM Fritz[®] cards (including USB versions), this option must be installed from the AVM software CD (refer to AVM ISDN analogue modem V32 BIS).

After the connection to a modem has been configured and set up, the SOL.Connect Center home page can be opened via a modem with the IP **http://192.168.2.1**.

5.3 Additional SOL.Connect devices

Details for connection and start-up of the optionally available SOL.Connect devices can be found in the supplied quick guide

5.4 Connection Large Display

5.4.1 Connection serial Display (direct connection)

The connectors of the large display need to be connected to pin A and B of the terminal strip of the data logger (A = Data+; B = Data-). With the completion of the necessary display configuration (see section. 7.6.2.4) in the data logger, data is sent to the connected display.




Image 5-4 Display connection

5.4.2 Connection of a remote display

Using a Serial-Ethernet converter (RS485) a supplied remote display can also be accessed via the Internet (UDP communication). For this purpose the necessary network settings for the Serial-Ethernet converter must be set in the data logger (see Section 7.6.2.4).

Data logger → network (Internet) → Serial-Ethernet- converter → display



Further information can be found in the display manual.

5.5 Electrical mains connection



Image 5-6 Plug-in power supply unit connection

Power supply via a plug-in power supply unit

The power supply is to be connected by means of the plug-in power supply unit (12 V-) included in the scope of delivery.

The data logger typically has a power consumption of circa 5-7 W.



Attention!

Connection to the mains supply must only be established after installation of the hardware and all other cables.

5.6 Switch-on

The data logger is ready for operation approximately **60 seconds** after connection to the mains power supply.

To ensure that all LED are functioning correctly, all LED will light briefly. The unit is now ready.

5.7 On-site verification of the installation

After installation an on-site verification should be done. For this purpose a direct connection to the SOL.Connect Center should be made via notebook:

- search for inverter (chapter 7.6.3.2)
- if applicable search for sensors (chapter 7.6.3.3)
- check measurement values for completeness

Should the inverter, sensors or other optional devices not be found, or the measurement values be incomplete, check the installation!

6 Mounting

The data logger is intended for mounting indoors or in switch cabinets. It may be mounted horizontally or in a suspended state (with connections facing downwards), on mounting rails, or on a wall with the brackets provided (see chapter Image 7-1).



Attention!

Like all other electronic devices, the data logger needs to be protected against moisture, especially condensation.




Image 6-1 Wall bracket

The data logger is hung on the mounting bracket by locking the screws on the rear of the device into the sockets on the bracket. When attaching the device care should be taken that the cable can be easily attached from below, avoiding strain on the cable!



Attention!

To avoid damage to the device the wall-bracket should be fixed using Rawl-plugs.

Mounting outdoors is only permissible inside suitable switch cabinets (protection class IP65).



Attention!

Connection or removal of any cables/wires should only be done when the device is switched off.

7 Working with the data logger

7.1 User rights, access rights

The data logger offers several access levels; settings are performed exclusively at the administrator level.

Access as „Guest“

Allows an anonymous visitor to view the plant state and reports.

Access as „User“

Allows read-only rights to plant state, reports, monitoring and downloads.

Administrator access

Additionally the Admin (administrator) is able to edit settings. For this purpose those with Admin rights need to authenticate themselves with a username and password.




Image 7-1 User authentication

By default, the user and password are both set to "**admin**" prior to delivery.



Attention!

To avoid unauthorised access by a third party (see chapter 7.6.4.2), the password must be changed immediately after the first login.

7.2 Start page

The data logger's main page provides an overview of the selected plant(s) operational status as well as the main menu.




Image 7-2 Start page

1 Menu navigation	5 Current plant power
2 Plant picture	6 Manual
3 Plant information	7 Your language
4 Plant state	8 User login

The **plant picture** (2), as well as pre-configured **plant information** (3) on the start page can be individually adjusted (see chapter 7.6.1.3).

The **plant state** (4) contains a status “traffic light” (chapter 11.2) and the performance ratio of the current PV plant conditions are displayed, as well as the time stamp (date/time) of the last event to have occurred. This leads by clicking directly to the monitoring.

In case of an alarm this will be shown visually on the start page and can be accepted with by a confirmation. Details see chapter 7.4.3.

If inputs such as switches are monitored, then the status „on“ will be shown.



Performance ratio only possible with a SOL.Connect MultiScan and irradiation sensor.

The **current plant power** (5) is displayed as a line diagram and shows the daily power of the plant. The sum of the power from individual inverters is shown on a time-axis. Further details to the reports can be found in 8.5,

If an irradiation sensor is incorporated into the sensor module, irradiation will also be shown.

The current **manual** (6) is available to download as PDF.

The **language option (7) of the web interface offers** several languages, which can be chosen individually at each session. By choosing the national flag, the user selects the desired language. At the end of the session (no operation of the web interface for about 10 minutes) the system language re-sets to default.

Details for configuring the default system language in chapter 7.6.1.5.

The **user login** (8) can be done directly via the start page, and along with the language choice will be reset to standard after finishing a session (no use of the web interface for ca. 10 minutes).

7.2.1 Sub-menu editing functions

Settings and changes are performed in the sub-menu of the selected function. Click on *Edit* to enter the required settings.

If you haven't yet logged in as an authorized user, you have to register as administrator. Setting changes are performed exclusively at the administrator level (see chapter 7.1).

Click on *Cancel* to discard new data and restore the previous settings.

Click on *Save* to save new data and overwrite the previous settings. Changes to the system and component configuration are logged as events by the monitoring function (see chapter 7.4).

In both cases, the editing window then closes automatically; click on *Edit* once again to perform further modifications.



For the use of some functions Java Script needs to be enabled. For details please consult your browser's manual.

7.3 Plant state

The plant state is a dynamic dialog in which current inverter data are scanned and listed in a tabular overview. The plant's *current* status is indicated here, this includes current power and event of each individual inverter.




Image 7-3 Plant state - inverter

The inverters will be shown as either grouped or ungrouped (see chapter 7.6.3.7).

This table provides brief details on **active** inverters (settings) including inverter name, output power, total daily yield and time of last data request. Settings to activating an inverter can be made under chapter 7.6.3.2.

The *Refresh* function can be used to restate inverter status and the system time is updated automatically.

An inverter's status details can be viewed by clicking on the inverter headline.

The screenshot shows the SOL Connect Center interface. The main header includes the logo and navigation links. The left sidebar contains a 'Main menu' with options like 'Plant state', 'Inverter', 'Sensors', 'Monitoring', 'Reports', 'Configuration', and 'Download'. The main content area is titled 'Plant state - Inverter' and shows the system time as 2008-08-01 14:29:19. Below this is a table of inverter data:

Name	Wechselrichter
Timestamp	2008-08-01 14:29:16
Serial number	0.00.7.07.03.02.002
Number	1
Language	German
Status	12
Error	0
DC voltage	339 V
DC current	0.8 A
DC power	285.7 W
Voltage	232 V
Current	1.1 A
Power	257 W
Income today	1.882 kWh
Temperature 1	0 °C
Temperature 2	27 °C
Temperature 3	29 °C

At the bottom of the table, there are two buttons: 'Refresh' and 'back'.

Image 7-4 Plant state - inverter status

The Data logger captured the energetic information, errors and conditions sent by the inverter. The information is dependant of the connected type of inverter (example on the basis inverters the SMA®).



Please check the manual of the inverter manufacturer for additional information to the inverter data.

Status details on sensors connected to the SOL.Connect MultiScan can be viewed by clicking on *sensors* in the navigation menu:

7.4 Monitoring

The monitoring menu provides an overview of all system events according to category.

All events are listed in detail and can be configured individually for the notification dispatch.




Image 7-5 Overview of monitoring

- **Configuration events**

Provides information on configuration changes, new message recipient, created and modified message recipients.

- **System events**

Provides general system events such as reboot internet access as well as occurred system events.

- **System details**

Important or special advices and event messages (e.g. problems with mail dispatch).

- **Inverter events**

Events reported from by inverters such as overvoltage, and overtemperature and grid failure.

- **No daily yield**

Inverter without daily yield

- **Low daily yield**

Yield deviation of the inverter from the averaged daily plant yield too high

- **Inverter failure**

Inverter wasn't reachable all day

The check of the plant monitoring (inverter failure, yield comparison and deviation) takes place **daily at 6 pm**. Settings for the monitoring options for the PV plant can be found in chapter 7.6.3.1.

To open the event group click on the headline of the group. All events recorded up to this point will automatically be displayed by the system.

Events are logged as follows:



Image 7-6 Monitoring protocol

All occurred events are shown here in chronological order. The most recent events are shown first.

The number of events to be shown per page can be individually set for each protocol.

By clicking *back* you will return to the overview.

7.4.1 Event notification (monitoring) editing functions

There are several functions available for editing (see also chapter 11.1). Moving the mouse over the symbols the description a so-called "tool tips" will be shown.

Notifications can be activated / deactivated directly in the overview using the symbols, or in the settings (see chapter 11).

Edit settings

Notification settings can be configured here.




Image 7-7 Configuration monitoring settings

The following settings are possible:

Parameter	Description
Notification	Activate/deactivate notification
Description	Short description of the monitoring group i Name of the monitoring group cannot be changed.
Frequency	Frequency of notification
Recipient	Recipient of the notification (also see chapter 7.6.2.3)

Notifications are dependant on the event group and the reaction latency (see chapter 7.6.3.1). The reaction latency is a threshold of a period of time that

an error must occur in order to trigger an event. During the *interval* is set primarily for sending of events.



Attention!

A notification can only be made by activating the notification function, entering an interval and notification recipient.

Permissible intervals for event groups are listed below.

Event group	Immediately without reminder	Immediately and hourly reminder	Hourly	Daily	Weekly
Configuration events			X	X	X
System events	X		X	X	
System details				X	X
Inverter events ^{*1}		X	X		
No daily yield				X ^{*2}	X
Low daily yield				X Fehler! Textmarke nicht definiert.	X
Inverter failure				X Fehler! Textmarke nicht definiert.	X

Immediately without reminder:

Immediately (following a reaction period if necessary); no reminder of a currently registered event is issued after that.

^{*1} Reaction latency

^{*2} Daily check at 6 pm, reports are issued later

Immediately and hourly reminder:	<i>Immediately</i> , followed by hourly reminders as long as the event is still registered.
Hourly:	<i>On every hour</i> , a check is made as to whether events in the event group occurred in the <i>previous hour</i> . New events are compiled and reported together with the remaining registered events.
Daily:	<i>Once daily</i> , a check is made as to whether events in the event group occurred the <i>previous day</i> . New events are compiled and reported together with the remaining registered events.
Weekly:	<i>Weekly</i> , a check is made as to whether events in the event group occurred in the <i>last seven days</i> . New events are compiled and reported together with the remaining registered events.

Activate /de-activate alarm

Clicking on the relevant icon (see chapter 11) will activate or de-activate the alarm. Checking or un-checking the checkbox in the settings will be automatically undertaken by the system.

All functions for editing event groups remain enabled even after alarm deactivation.

7.4.2 Email messages

According to the notification- and recipient settings event notification will be sent by Email. The Email language corresponds to that set by the Email recipient.



Attention!

Using exclusively a modem the email dispatch only in conjunction with active internet dial-in (Dial-out switch) possible, see also chapter 4.1.

Emails whose delivery failed as a result of incorrect addressing, for instance, are logged in the system details. Incorrect addresses should be rectified as soon as possible.

i Should several people require simultaneous information, it is recommended to use a distribution list (e.g. support@address.com).

7.4.3 Notification via alarm

If a device, e.g. lamp has been connected to the alarm contact of the data logger, the message recipient (7.6.2.3) *alarm contact* needs to be set up, activated and selected as message recipient.

If an alarm is triggered, an alarm confirmation appears on the start page of the data logger, which can either be acknowledged by pressing the „alarm-off“-button or will automatically be deactivated by the system after the alarm duration (chapter 7.6.2.3) has passed.

Plant state	
Current overall state:	●
Total power:	758 W
Total day yield:	6.3 kWh (2.52 €)
Performance ratio:	82 %
Alarm is switched on. Please acknowledge:	<input type="button" value="» Alarm off"/>

Image 7-8 Activated alarm

i The reaction time of the relay can be up to 5 minutes. This can lead to a slight delay in switching of the alarm contact.

The acknowledgement of an alarm is tracked in „configuration events“.

7.5 Reports

Reports provide a variety of graphic data evaluation reports in **energy reports**, representing power and yield in relation to occurred inverter **events**.

It is possible to switch over between days and months here.



Image 7-9 Overview of evaluations

In dependence of the monitoring periods different diagram possibilities result:

- **Daily power of entire plant**

Daily power of plant (line diagram)

- **Daily yield of inverters**

Daily overview of each inverter yield (bar chart)

- **Monthly yield of entire plant**

Monthly plant yield of all inverters (bar chart)

- **Normalized month yield**

Plant yield of a month based on 1 kWp (bar chart)

- **Annual yield of entire plant**

Annual yield of plant and inverters (bar chart)

- **Performance ratio of whole plant**

Comparison of nominal and actual values of the plant by using reference sensors (bar chart)



Performance Ratio only in conjunction with SOL.Connect MultiScan + irradiation sensor.

Depending on the individual report type the report generation can be influenced by different selection possibilities, which will be shown on the time-axis as either a line graph or bar chart.




Image 7-10 Report navigation protocol

Inverter groups will be shown first as default, after selecting a group of related inverters.

i Selection in daily power and performance ratio not possible.

Events are logged as follows:



Image 7-11 Report event protocol

Additionally all events are shown in chronological order below the diagram. As in the monitoring, the most recent events are shown here first.

i The maximum of the power axis is the same as the capacity rating (see chapter 7.6.3.1) of the plant.

7.5.1 Reports editing functions


All reports and corresponding notifications can be individually adjusted to the system.

Notifications can be either directly shown in the overview (admin right necessary) or activated/deactivated in the settings.

Moving the mouse over the symbols the description a so-called "tool tips" will be shown.

Edit settings

The following settings are possible:

Parameter	Description
Notification	Activate/deactivate notification
Description	Short description of the monitoring group  Name of the event group cannot be changed.
Interval	Frequency of notification
Display event	Activate/deactivate the display of events (except yearly diagram).
Recipient	Recipient of notification



Attention!

A notification can only be made by activating the notification function, entering an interval and notification recipient.

Permissible intervals for report groups are listed below.

Evaluation group	Hourly	Daily	Weekly
Daily power	X	X	
Daily yield	X	X	

Evaluation group	Hourly	Daily	Weekly
Monthly yield ¹		X	X
Normalized monthly yield		X	X
Yearly yield			X

Hourly: *On every hour, an updated report together with occurred events is issued.*

Daily: *Every day, an updated report together with occurred events is issued.*

Weekly: *Every Monday, an updated report together with occurred events is issued.*

The dispatch time can be configured under Email service (see chapter 7.6.2.1).

Activate /de-activate notification

Clicking on the relevant icon (see chapter 11) will activate or de-activate the notification. Checking or un-checking the checkbox in the settings will be automatically undertaken by the system.

All functions for editing event groups remain enabled even after notification deactivation.

¹ If the dispatch time is not equal to the month or end of the year, then an additionally email is sent

7.5.2 Email messages

According to the email and recipient settings reports are sent via email. The email language corresponds to the set mail recipient languages.



Attention!

Using exclusively a modem the email dispatch only in conjunction with active internet dial-in (Dial-out switch) possible, see also chapter 4.1.

Emails whose delivery failed as a result of incorrect addressing, for instance, are logged in the system messages. Incorrect addresses should be rectified as soon as possible.



Should several people require simultaneous information, it is recommended to use a distribution list (e.g. support@address.com).

Emails whose delivery failed as a result of incorrect addressing, for instance, are logged in the system messages. Incorrect addresses should be rectified as soon as possible.

7.6 Configuration (Administrator domain)

Clicking on *configuration* opens an overview of the current system configuration and information settings of the data logger, such as free and used hard disc capacity (Compact Flash[®] card) and main memory.

From here settings can be made in further sub-menus such as network, internet dial-up, Email etc.

The screenshot displays the SOL.Connect Center web interface. The header includes the logo 'SOL.Connect Center' and the tagline 'Monitoring, Visualisierung und aktive Kommunikation'. A navigation menu on the left lists: Main menu, Plant state, Monitoring, Reports, Configuration (selected), Core system, Communication, Solar plant, Security, and Download. The main content area is titled 'Configuration - System information' and contains the following data:

System name:	SOL.Connect Center
Host name:	SCC
System is running since:	48 day(s)
System time:	2008-08-06 13:50:16
Hard disk capacity:	962MB total, 778MB free, 13% used.
Main memory:	61MB total, 49% used.
Serial number:	0050C229F13A
Software version:	1.1
Hardware version:	1.2

Image 7-12 System information

The information shown here, such as host name, system name (see chapter 7.6.1.1) and system time (chapter 7.6.1.4) can be set in the relevant sub-menus. Details are given in the following chapter.

Information about hardware or memory is refreshed automatically by the data logger and cannot be edited.

7.6.1 Core system

7.6.1.1 Network

Under *Network*, settings such as host name, domain name, IP address, broadcast address, subnet mask, standard gateway and DNS server are set. These are pre-defined at factory level.

Options here include *own settings* (default) or *DHCP settings* (to be requested from the LAN administrator. DHCP settings employ different IP addresses.



DHCP: Dynamic Host Configuration Protocol - dynamic allocation of IP addresses. The data logger passes on the host name to the DHCP, so it can be found in the network more easily.

The data logger forwards the host name to the DHCP server. This enables it to be found more easily in the network.



Attention!

To avoid serious connectivity problems with data logger, these parameters should only be edited in consultation with your network administrator.

Settings can be configured with *edit*.




Image 7-13 Network configuration

The following settings are possible:

Parameter	Description
Operating mode	Operating mode of the data logger system. Setting can only be changed by service.
Host name	E.g. my host
Domain name	Name of domain. Ask your network administrator for the domain name.
IP address	Only active if no DHCP Server is setup. Default entry: 192.168.1.190
Broadcast address	IP address for communicating with all computers in a network.
Subnet mask	Default entry: 255.255.255.0
Standard gateway	IP address of the internet gateway. This address can be requested from your network administrator.
DNS server	This parameter can be requested from your network administrator.



Default network settings for Internet access via a modem:

- IP address: 192.168.1.190
- Subnet mask: 255.255.255.0
- Standard Gateway: <empty>
- DNS server: 192.76.144.66

7.6.1.2 Modem

Under *Modem*, you enter modem and dialling parameters such as modem type, PIN, access number, login name and password etc. necessary for dialling into the Internet



Image 7-14 Modem configuration

Settings can be configured with *edit*.

The following settings are possible:

Parameter	Description
Modem type	Type of the used modem.
Baud rate	Maximum transmission rate of the connected modem.

Parameter	Description
Additional modem command	Configuration command for modem operation with software flow control.
PIN (for GSM)	GSM PIN code. This code can be requested from the provider. <i>If a GSM modem is being used, this code is a prerequisite for establishing connections.</i>

Parameter	Description
Multipile call numbers:	Multipile call number (MSN) is an ISDN call number for a multiple appliance connection.
Number of rings	Number of rings until the modem automatically takes the call.

Parameter	Description
Access number	Number of the target computer / provider, e.g. 0192658. If extensions are in use, do not forget to specify an exchange number.
Dial-up command:	Configuration command e.g. for internet dial-up via GPRS
Login name	User name, e.g. MSN.
Password	password



A standard modem (analogue) is pre-configured into the system. If a network connection is not possible alternatively, a standard modem can be connected and used as dial-up

- Standard modem settings for Internet connection via MSN:
- Dial-in number: 0193670
- Login: msn@easysurfer-eco.de
- Password: msn
- Dial-in number for extensions
- Dialup commands: ATX3

- Dial-in number: 0193670



Attention!

When using a GSM modem near country borders the international roaming feature must be deactivated by the provider, to save over-seas connection costs. Please consult your provider.

A prerequisite for Internet access is that the Dial-Out Switch is in the "on" position. This switch can be found on the backside of the data logger (see chapter 4.1). The current position of the switch can be seen on the overview of the modem configuration.

If all configurations have been made *the modem dial-up to internet* can be tested before start-up (function in modem configuration overview).

It is standard with certain modems that when switched on the flow control is deactivated. For such modems, therefore, the extra modem command to activate hardware flow control **MUST** be given!

It apply to modems following commands:

- Modems Siemens MC/TC35 require: `„AT\Q3`
- INSYS® ISDN 4.0: `AT&R1&S1`



Attention!

To avoid unforeseen costs it is advised to de-activate the internet access as soon as it is no longer required.

If Internet connection is de-activated no messages can be sent.

7.6.1.3 Plant details

Under *plant details*, you can find the configuration for the start page. Besides creating a plant picture, you can specify a name*, description, owner and other plant-related details.

* Mandatory field




Image 7-15 Editing the start page

The plant picture can be activated / de-activated via a checkbox. To enable graphic display, the checkbox *Show on welcome page* needs to be marked and an image file needs to be uploaded.

Click on *Browse* and then on *Open* to upload a locally saved graphics file complying. Click on *Save* to display the image on the main page. If an image does not comply with the graphics requirements, the previous graphics setting is retained.

Recommended size: 605x250 Pixel

Format: JPG

Click on *Add text* and then fill the *Description* (max. 200 characters) and *Text* (max. 30 characters) fields to create a new row of details.

You can click on *Add text* repeatedly to add any required number of new rows to the current one.

Clicking on *Save* displays the created rows of information on the main page



Text can be formatted by means of HTML tags.

Deleting a row's contents and clicking on *Save* deletes the row, except the name.

7.6.1.4 System time

The *System time* indicates the current time in the data logger. This value can be adjusted manually or synchronized via NTP time server.

i NTP: "Network Time Protocol" standard for synchronizing clocks in computerized systems.

i The NTP time server is not enabled by default. It is recommended to activate it after start-up. Addresses can be found in the Internet about.



Image 7-16 System time configuration

Settings can be configured with *edit*.

Additionally, you can set a *Time zone* although it **does not influence the system time**. Permitting a display of locations within the selected time zone, this option relies on the time value entered beforehand.

Defined time zones are listed below.

Time zone	Cities (excerpt)
<i>GMT: Greenwich Mean</i> UT: Universal UTC: Universal Coordinated WET: Western European	(GMT*) Casablanca, Monrovia, Dublin, Edinburgh, Lisbon, London
CET: Central European	(GMT* +01:00) Amsterdam, Berlin, Bern, Rome, Stockholm, Paris
<i>EET: Eastern European</i> CAT: Central Africa Time SAST: South Africa Standard Time	(GMT* +02:00) Athens, Istanbul, Minsk, Cairo, Jerusalem
<i>EAT: East African</i> BT: Baghdad MSK: Moscow Time	(GMT* +03:00) Baghdad, Moscow, Nairobi



Attention!

Change of the time zone requires reboot of the system!




Abbildung 7-1 Konfiguration Zeitserver Systemzeit

* GMT= 12.00

Settings can be configured with *edit*.

To change the times manually enter *Date* and *Time*.



Attention!

Caution when changing system time! A time difference of **more than 10 minutes** can lead to problems with the data which has already been recorded.

To synchronize with the time server, check the server time replication option. Once a modem connection is active, the system time is compared with the time server's value.

Time server synchronization depends on connection settings and the conditions listed below.

Time	Connection	Condition
5 am daily	Network connection	Correct DNS and gateway settings; see chapter 7.6.1.1.
After successful connection setup	Modem link	Connection needs to be established by the data logger.

Switchover to and from daylight savings takes place automatically.

7.6.1.5 System language options

The standard system language of the data logger is set to German at factory level, but can be individually set for each system.




Image 7-17 Configuration system language

Settings can be configured with *edit*.

By choosing and saving a new system language can be set. The chosen language will be used at the next session.

7.6.2 Communication

7.6.2.1 Email service

Under *Email service*, you specify mail-server settings for exchanging Emails. Parameters here include SMTP server, login, password, and sender address and authentication type.




Image 7-18 Configuration of mail service

Settings can be configured with *edit*.

The following settings can be made here:

Parameter	Description
SMTP server	(Simple Mail Transfer Protocol server) outbox server; this information can be requested from your Internet provider (see below) or LAN administrator.
Login	Internet provider's user name.
Password	Password assigned by the Internet service provider. <i>For security reasons, every password character is displayed as an asterisk (*).</i>
Sender address	Sender's Email address used for authenticating the SMTP server. An unknown sender address can cause Email delivery to fail.
Authentication type	Authentication – SMTP – on; the account information of the email will be given by the internet provider. As authentication type exclusively SMTP Authentication is supported!

Additionally an individual send-time is possible:

Parameter	Description
Send-time Emails (daily):	Send-time for daily Email. Manual input of time not possible.
Send-time Emails (weekly):	Send-time for weekly Email. Manual input of time not possible.

Emails to be sent can also be exchanged via free Email providers.

Requirement for email exchange is a *SMTP* server on the side of the Email service provider.

Attention!



Not every provider offers this service free, check whether **fees are charged for Email accounts** such as Premium / Plus / Extra / Professional etc.

7.6.2.2 Familiar free Email and online services

The most familiar free Email providers are listed below.

GMX*

Incoming mail server: POP3: pop.gmx.net, IMAP: imap.gmx.net

Outgoing mail server : mail.gmx.net

User name: GMX customer number or GMX Email address (use of the customer number is recommended)

Special features: Uses SMTP authentication or POP3 before SMTP, depending on your account configuration.
IMAP is only available at ProMail and TopMail rates.

* Details not guaranteed. This information should be verified by the service providers.

Google mail*

Incoming mail server: pop.googlemail.com (SSL; port 995)
Outgoing mail server : smtp.googlemail.com (SSL; port 465 or 587)
User name: username@googlemail.com
Uses SMTP authentication.
POP3 and SMTP are SSL-encrypted.
Special features: SMTP server runs on port 465 or 587; POP3 server runs on port 995 (standard port for POP3 via SSL).

Hotmail*

This Email provider does not offer any POP3 or SMTP services.

An account requiring payment can be used to access mail via HTTP mail protocol in Outlook and/or Outlook Express.

The HTTP mail address is:

<http://services.msn.com/svcs/hotmail/httpmail.asp>

Lycos mail*

Incoming mail server pop.premiummail.lycos.de
Outgoing mail server smtp.premiummail.lycos.de
User name Complete Lycos Email address
Special features Uses SMTP authentication.
POP3 and SMTP are only available at extra charge. To avoid payment, you can access your Lycos account via HTTP mail. As a registered user of "The Bat!" Email program, however, you can use POP3 and SMTP free-of-charge. In this case, though, you will receive Email advertisements from Lycos partners.

The HTTP mail address is:

<http://webdav.lycos.de/httpmail.asp>

* Details not guaranteed. This information should be verified by the service providers.

WEB.DE FreeMail*

Incoming mail server POP3: pop3.web.de, IMAP: imap.web.de
Outgoing mail server smtp.web.de
User name User name
Special features Uses SMTP authentication or "POP3 before SMTP".

Yahoo! Mail*

Incoming mail server pop.mail.yahoo.de
Outgoing mail server smtp.mail.yahoo.de
User name User name
Special features Uses SMTP authentication. To make use of POP3 and SMTP, you first need to register with Yahoo! directly. Free access via POP3 and SMTP is only possible for mail accounts registered with Yahoo! Deutschland (i.e. the domain of your Yahoo! Address is yahoo.de). Addresses in the yahoo.com domain come at an extra charge.

Available online services (registration necessary) are listed below.

T-Online*

Incoming mail server pop.t-online.de
Outgoing mail server mailto.t-online.de
User name Any
Special features Any user name and password are permissible; these parameters can even be left out completely, provided that you have logged in via T-Online.

Freenet¹

Incoming mail server mx.freenet.de (POP3 and IMAP)
Outgoing mail server mx.freenet.de
User name username@freenet.de
Special features Uses SMTP authentication.

¹ Details not guaranteed. This information should be verified by the service providers.

7.6.2.3 Message recipient

Under *Message recipient*, you manage the recipients of reports and notifications. There are different types of notification recipient. As well as email there are also alarm contacts and a recipient for data upload into the SOL.Connect Portal is possible.



Attention!

Email dispatch is only in conjunction with a modem and active internet dial-up (dial out switch) possible, see chapter 3.4.5.

Click on '*New*' to create a new recipient; set the recipient status to *Active/Inactive* as required by marking/removing the "tick".

There are various types of message recipients:

Email

Electronic sending/ receipt of messages

The screenshot shows the SOL.Connect Center web interface. The header includes the logo and navigation links like 'Manual' and 'Your language'. A sidebar on the left contains a menu with options like 'Main menu', 'Plant state', 'Monitoring', 'Reports', 'Configuration', 'Core system', 'Communication', 'Email service', 'Message recipients', 'SOL Connect Portal', 'Solar plant', 'Security', and 'Download'. The main content area is titled 'Configuration - Message recipient - Edit' and contains the following form fields:

- Type: Email (dropdown menu)
- Name: my name (text input)
- Email address: myname@myaddress.com (text input)
- Status: active (checkbox)
- Recipient Language: English (dropdown menu)

Below the form, there is a note: 'After setting up the message channel notification setting can be made here.' and two buttons: 'Save' and 'Cancel'. A legend at the bottom indicates '* Mandatory field'.

Image 7-19 Message recipient - Email

The following settings can be made here:

Parameter	Description
Type	Email
Name*	Recipient's name, e.g. My name
Email address*	Recipient's Email address in the Internet, e.g. my-name@myaddress.com . Email addresses are allocated by the provider or online services such as free Email (see chapter 7.6.2.2).
Status	Via activating / deactivating the checkbox the message recipient can be set to active/inactive. i Recipients already configured, can be de-activated temporarily (e.g. for vacation periods).
Recipient's language	Language of the Emails to be sent to the recipient.

Short email

Electronic sending / receiving of messages. Unlike in Emails important information is only submitted in the subject of the message. This allows the forwarding of the message as SMS (text message) to a mobile phone.

Example: Day yield - Plant name (2007-03-20) = 34.340 kWh

Settings for sending a short email can be found in type Email.

* Mandatory field

Alarm Contact

To connect sirens and lamps. For this the alarm contact has to be connected to the relay output of the data logger (see chapter 4.1).




Image 7-20 Message recipient – alarm contact

The following settings are possible:

Parameter	Description
Type	Alarm Contact
Name	Recipient's name, e.g. 10 minute alarm
Alarm Pe- riod	The duration of the connected sirens/lamps can be set here.
Status	Setting or removing the check mark will activate/de-activate the alarm contact.

The alarm contact will switch off automatically after the chosen duration or can be switched off manually with "Alarm Confirmation" (chapter 7.4.3)

FTP-Upload

Uploading of data sets to the data logger to a server (or SOL.Connect Portal, chapter 3.4)

The screenshot shows the 'Configuration - Message recipient - Edit' page in the SOL.Connect Center. The interface has a blue header with the logo and navigation links. A sidebar on the left contains a menu with options like 'Main menu', 'Plant state', 'Monitoring', 'Reports', 'Configuration', 'Email service', 'Message recipients', 'FTP-Upload', 'Solar plant', 'Security', and 'Download'. The main content area contains a form with the following fields: 'Type' (dropdown menu set to 'FTP'), 'Name' (text input 'Max.Mustermann'), 'Destination server' (text input 'zelserver.de'), 'Login' (text input 'muster'), 'Password' (password field with four asterisks), and 'Status' (checkbox labeled 'active'). Below the form are 'Save' and 'Cancel' buttons. A note at the bottom indicates '* Mandatory field'.

Image 7-21 Message recipient - SOL.Connect Portal

The following settings are possible

Parameter	Description
Type	FTP
Name	Name, e.g. inverter data
Server	sol-connect.de
Login	Login
Password	Password
Status	Setting or removing the check mark will activate/de-activate the alarm contact for the message dispatch. <div style="display: flex; align-items: center;"> <div style="font-size: 2em; margin-right: 10px;">i</div> <div> <p>Via status, existing recipients can be temporarily de-activated (e.g. when on holiday).</p> </div> </div>

If a recipient has been set up then the notification for dispatch can be configured. This does not apply to the message recipient *FTP-Upload!*




Image 7-22 Notification for message recipient

When recipients have been set up it is possible to *edit* settings, with the exception of receiver type. After saving it can no longer be changed. A new recipient type must be setup.

7.6.2.4 FTP-Upload

The FTP upload to a server or e.g. SOL.Connect Portal (for details see accessories section 3.4) allows uploading of data logger records.

With a fast internet connection to SOL.Connect Portal data can be downloaded, and power/ yield diagrams produced.



Image 7-23 SOL.Connect Portal – sensor data

The following settings are possible:

Parameter	Description
Notification	Data transfer activated/deactivated by marking/unmarking tick box.
Description	Individual short description of the group. Leaving column free sets the description back to standard text.
Interval	Frequency of data transfer.
Recipient	Message recipient FTP

A prerequisite for uploading data sets is an active recipient to the FTP (see chapter 7.6.2.3).

The following shows the possible intervals compared to the FTP-Upload groups:

Group	hourly	daily
Sensor data	X	X
Inverter details	X	X
Events	X	X

The send-time can be set under Email services (see chapter 7.6.2.1).

Data transfer activation/deactivation

The upload can either be activated / deactivated in the overview or settings.

When you move the mouse over any one of the icons, a tool tip describing the related function appears see chapter 11.1.

7.6.2.5 Display (optional)

The control needs to be set up according to the connected display (see chapter 5.4) and nominal plant power.



Abbildung 7-2 Konfiguration Display

Folgende Einstellungen sind möglich:

Parameter	Description
Display type	HVG or HVG plant power > 100kW
Connection	Serial Interface (COM3-RS485) or remote display
Address *	IP-address or Serial-Ethernet converter name (remote display only)

* nur bei Auswahl Ferndisplay

Parameter	Description
	i Input IP-address without <i>http://</i> prefix.
Port*	Port-setting of the Serial-Ethernet converter
Refresh every	refresh period of displayed data



Attention!

By saving the display configuration, the system will automatically re-start..

7.6.3 Solar plant

7.6.3.1 General settings

Under *Solar plant*, you can individually edit and view details on the entire plant, including the monitoring options set for the PV plant.



Image 7-24 Solar plant

Settings can be configured with *edit*.

The *Supervisory options* are used for monitoring (alarm) of the inverter.

Inverter failure

If '*Inverter failure*' is activated, an alarm is issued on a failure of any inverter. An inverter is assumed to have failed if it does not communicate with data logger for an entire day.

Minimum-Performance ratio

An alarm will be given if the power and the determined minimum performance ratio (percentage ratio of performance variation) is exceeded.

i Performance ratio only in conjunction with a SOL.Connect MultiScan + irradiation sensor.

Income deviation

The yield variation can only be compared when two or more inverters are active.

An alarm is issued if an inverter supplied insufficient energy compared with the remaining inverters on the previous day. This is attributable to soiling, partial failure of solar cells, or a faulty inverter circuit.

The *Income deviation* field is used to specify a percentage of the mean value serving as a basis for evaluating yield. The settings below must be performed for yield deviation.

- **Income deviation:** Percentage deviation of an inverter's income from the expected share.
- **Minimum income for comparison:** A minimum income can be specified to avoid incorrect alarming on days with low levels of solar irradiation. If the plant's total income falls short of the minimum level, no energy comparison or alarming takes place.
- **Installed peak power:** The maximum power must be entered manually in the corresponding field [Wp]. A value of "0" de-activates monitoring of the inverter's income.
The maximum power can be set individually for each inverter in 10.5.9 *Configuration\Inverters*.

Evaluation is performed as described below.

Each inverter's daily income is divided by the maximum power of its installed solar modules.

An inverter's relative income is determined as follows:

$$\text{Relative income} = \text{Energy per day [kWh]} / \text{installed power [kWp]}$$

The relative income is compared with the remaining inverters' output. If the percentage deviation exceeds the set minimum value, an alarm is issued.

Reaction latency

Additionally the time interval to alarm issue ("*reaction latency*") can be set for the inverters (immediately = alarm issued immediately after event).

It is possible to send alarms via Email. Thereto a message recipient (7.6.2.3) needs to be created and activated.

i False alarms due to seasonal and weather-related factors such as snowfall and twilight are not to be ruled out.

7.6.3.2 Inverter

Under Inverter, you can view and individually configure all inverters detected by the system. You can also search for new inverters here.

The inverter *Search* function permits easy scanning for all operational, enabled inverters (also known as *scanning*) and is necessary for working with the data logger.



Image 7-25 Inverter search

A search can be renewed at any time; all newly found inverters are included in the search log.

Clicking on the serial number of an inverter opens the related settings.



Image 7-26 Inverter configuration

i *Delete* removes the inverter from the system. Note the information provided under automatic network *search*.

The following settings can be made here:

Parameter	Description
Inverter serial number	Assigned by the manufacturer, this serial number cannot be changed.
Inverter description*	Unique description for the inverter (compulsory entry). Special characters or blanks spaces are not permissible here. i The descriptions are in used for the inverter reference in the reports.
Inverter group*	Here you can individually define an inverter group. One or more groups can be specified (e.g. group 1, group 2 etc.). Inverters are displayed in accordance with their group affiliation.

* Mandatory field

Parameter	Description
Inverter status	The inverter monitoring can be set to active/inactive via activating / deactivating the checkbox. Only active inverters can be called up, inactive inverters will be automatically hidden.
Monitoring	An active inverter can be activated/deactivated for monitoring purposes (configuration under general settings 7.6.3.1)
Max. input power (AC-power)	The maximum power calculated so far is indicated here which can be entered manually or overwritten automatically from the system if a higher value is registered.

Inverter settings must be performed individually for each connected inverter.

Automatic network scan

At 10.00 am and 2.00 pm every day, the system commences a network scan. This permits the data logger to search for connected inverters. Inverters not yet registered are added automatically to the configuration event log (see also chapter 7.4).

i Deleted inverters with an active status are added again automatically during the network search procedure. Deactivating the Inverter status checkbox can prevent this.

7.6.3.3 Sensors (optional)

Additional sensors can be connected and scanned via the data logger. All sensors detected by the system can be viewed and individually configured in the Sensor menu.

The *Search* function permits an easy scanning for the sensor module.




Image 7-27 Search sensor modules

Clicking on the sensor module option opens the related settings window.



Image 7-28 Sensor modules

i *Delete* removes the sensor module from the system. Note the information provided under *automatic network scan*.

The following settings can be made here:

Parameter	Description
Address	81
Name	Unique designation for the sensor module (compulsory entry).
Group	Here you can individually define groups. (This can be 1 or more groups. E.g. Group 1, Group 2.) The sensor module is displayed in accordance with their group affiliation.
Status	By marking this checkbox, the sensor can be set to <i>Active</i> and accordingly scanned by the system status monitor. Inactive sensors are automatically hidden from view.

Sensor

Parameter	Description
External temperature	Gives an Offset (delta value) for the correction of the external temperature.
Module temperature	Gives an Offset (delta value) for the correction of module temperature.
Irradiance sensor	Selection of sensor type. The calibration value indicates the voltage generated by the sensor when an irradiance of exactly 1000 W/m ² is attained. This value is normally noted on the irradiance sensor. The default setting is 75 mV.
Pulse counter	Indicates the number of pulses generated by the yield counter per kWh. The default value here is 1000, i.e. the yield count increases by 1 kWh every 1000 pulses.
Power (transformer) (0-20mA)	The calibration value indicates the maximum plant power which 20mA corresponds on the output.

7.6.3.4 In-/Outputs

Inputs can be configured for monitoring and linked to the relay output.

Input




Image 7-29 Input configuration

The following settings are possible:

Parameter	Description
Name	PIN description (switching terminal strip see chapter 4.1)
Description	Individual naming of the input possible.
Status	Activation/Deactivation of the input.
Output	Selection of output

i *Function switch (Func 1)* is for configurable for any function.

Output

The screenshot shows the 'Configuration - Inputs and outputs - Edit' page in the SOL Connect Center. The interface includes a top navigation bar with 'Manual', 'Your language', 'Welcome', and 'Login'. A left sidebar contains a 'Main menu' with options: 'Plant state', 'Monitoring', 'Reports', 'Configuration', and 'Download'. The main content area features a form with the following fields: 'Name' (OK1), 'Description' (empty text box), 'Status' (checked 'active'), and 'Output' (OK1 dropdown menu). At the bottom of the form are 'Save' and 'Cancel' buttons.

Image 7-30 Output configuration

The following settings are possible:

Parameter	Description
Name	PIN description (switching terminal strip see chapter 4.1)
Description	Individual naming of the outputs possible.
Status	Activation/Deactivation of the outputs

By attaching inputs to relay outputs message channel of type alarm contact will be deleted.



Attention!

A prerequisite for a link is an active in- and output.

7.6.3.5 Control station

Configuration can only be displayed and changed for a data logger operating in control station mode.



For active control station mode see enclosed Quick Guide.

7.6.3.6 Reimbursement

To show the financial yield as reports certain settings have to be made. It is possible to either calculate the reimbursement according to the German Gesetz für den Vorrang Erneuerbarer Energien (EEG) or to freely define the reimbursement sets.

Depending on selection only the collected data will be adjusted.

Reimbursement according to German EEG Novelle

To calculate the reimbursement according to EEG the plant type, plant size in kW, the installation year and currency must be entered. The reimbursement according to EEG is preset and is calculated automatically.

The screenshot shows the 'Configuration - Reimbursement - Edit' page in the SOL.Connect Center. On the left is a sidebar menu with options like 'Main menu', 'Plant state', 'Monitoring', 'Reports', 'Configuration', 'Core system', 'Communication', 'Solar plant', 'General settings', 'Inverter', 'Sensors', 'Control station', 'Reimbursement', 'Administration of groups of inverter', 'Power management', 'Security', and 'Download'. The main content area has a 'Reimbursement' dropdown menu set to 'Reimbursement as per EEG amendment'. Below this is the 'Plant information' section with the following fields: 'Plant type' (Open land), 'Size of the plant' (10 kW), 'Year of installation' (2000), and 'Reimbursement' (34.93 ct/kWh). There are 'Save' and 'Cancel' buttons. At the bottom, there is a note: '* Mandatory field ** Reimbursement settings can only be set for complete months. Therefore please select any date of the relevant month.'

Image 7-31 Reimbursement according to German EEG Novelle

Self defined reimbursement model

A self defined reimbursement model can be set manually with a reimbursement period and amount per KWh. With this all possible international reimbursement models should be calculable. However, this manual definition requires a good knowledge of the individual reimbursement models.



The screenshot shows the 'Configuration - Reimbursement - Edit' page in the SOL Connect Center. The left sidebar contains a navigation menu with options like 'Main menu', 'Plant state', 'Monitoring', 'Reports', 'Configuration', 'Core system', 'Communication', 'Solar plant', 'General settings', 'Inverter', 'Sensors', 'Control station', 'Reimbursement', 'Administration of groups of inverters', 'Power management', 'Security', and 'Overload'. The main content area is titled 'Configuration - Reimbursement - Edit'. At the top, there is a dropdown menu for 'Reimbursement' set to 'Self defined reimbursement model'. Below this is the 'Plant information' section with fields for 'Plant type' (Open land), 'Size of the plant' (10), 'Year of installation' (2000), and 'Currency'. The 'Reimbursement' section features a table with columns 'Start date', 'End date', and 'Reimbursement'. A single row is visible with a green checkmark in the 'Reimbursement' column. At the bottom of the form are 'Save' and 'Cancel' buttons. A note at the bottom states: '* Mandatory field ** Reimbursement settings can only be set for complete months. Therefore please select any date of the relevant month.'

Image 7-32 Self defined reimbursement model

To enter the reimbursement period and amount add a column and save it with an end-date. Symbol descriptions can be found in the hand book under chapter 11.1.



Reimbursement period can only be set as complete months!

7.6.3.7 Administration of groups of inverter

If a PV plant is made up of many inverters and plant parts, it often becomes difficult to maintain an overview of the plant as a whole. This function allows groups and their inverters to be easily controlled and viewed.




Image 7-33 Administration of group of inverter

The following settings are possible:

Parameter	Description
Group	Available groups
Name of the group	Name of group chosen or to create

To group an inverter to a group or to allocate/delete to another group the tick box for the inverter has to be marked/unmarked. Additionally one must chose to create a new group, or create with new.

A group can only be run in conjunction with an inverter.

Delete will not remove the inverter from the system, but will remove only the group, and will be shown as *ungrouped*.

7.6.3.8 Power Management (optional)

For the *Power Management* of the SOL.Connect Power Manager the status for the rof the relay setting of the ripple control is to be configured.




Abbildung 7-3 Konfiguration Leistungsmanagement (SOL.Connect Power Manager)

The following settings are possible:

Parameter	Description
Validation period of signal	Duration of the signal test of the ripple control
C 1 ... C4	Channel 1 to 4 from the ripple control
Active	To activate/deactivate the function
Operation mode	Active power requirements
Maximum active power	0 – 100% of active power



Attention!

A active power of 0% does not reduce the power output completely to 0W. There remains a minimal residual power which is fed in by the inverters.

7.6.4 Security

7.6.4.1 Public access

The start page, plant state and reports can be shown publically and use for e.g. demonstration purposes. To see further details a login is necessary.



Image 7-34 Public access

7.6.4.2 Passwords

Under *Passwords*, you can find the password administration for the system administration and user.




Image 7-35 Passwords

Password configuration can be changed with *edit*.

The password must have between 6 and 16 characters.

7.7 Download

7.7.1 Plant data

The download function makes it possible to view and save data locally.




Image 7-36 Download overview

- **Plant sum**

Contains values for the total income today, power, recording time stamp, as well as irradiation and irradiation income today.

- **Inverter details**

Provides detailed information on each selected inverter.

- **Sensor data**

Contains detailed information and recording time stamp of the sensors on each selected value.

- **Plant events**

Lists events, details, warnings and errors.

The download page displays all the information available in the data logger in the following order:

- Logged data (fixed entries in the case of events)
- Period
- Record size (KB or MB)

This page again displays additional details on the log type. Depending on the selected type, the download form displays a list comprising data columns.

The screenshot shows the 'Download - Plant summary' interface. On the left is a navigation menu with 'Download' highlighted. The main content area contains a form with the following fields:

Data:	Timestamp, Datalogger number, Power, Income today, Measured income, Irradiation, Irradiation income today
Period:	2008-05-20 to 2008-07-17
Record size:	32 KB
from:	2008-07-15
to:	2008-07-17
File type:	*.txt <input type="checkbox"/> compressed transmission

At the bottom of the form are 'Download' and 'Cancel' buttons.

Image 7-37 Download formula side

The following download criteria can be defined:

- Desired period in days. All data records logged within this period are downloaded.
- Desired data columns. This does not apply to the plant summary which is downloaded in a fixed data format.
- File format .txt (text)
- Additional choice of compression which allows a quicker data download e.g. when dealing with large data volumes or a slow modem connection.

Click on *Download* to start the download process. Download can take a few seconds. As soon as it is complete, a separate window appears for opening or saving the file. This window can be used to save the data file to your local hard-disk or view *Open* it directly with the associated program.



File download might be prevented by pop-up blockers in Internet Explorer[®], Firefox[®] and/or firewall software.

Note the respective program supplier's usage instructions and options.

7.7.1 Documentation

To download the associated documentation in .pdf format

Zum Download der zugehörigen Benutzeranleitung in .pdf Format.



Abbildung 7-4 Dokumentation Download

8 XML-Upload via SOL.Connect Centers mpp

Depending upon to the user configuration the **SOL.Connect Center** transfers cyclically its logged measuring values into XML files and once per hour to a FTP server in a defined hierarchy and nomenclature:

SOL.Connect Center serial number

↳ Type measuring device (MultiScan, SMA)

↳ timestamp.xml.gz

Example:

CI8000P1400

↳ MultiScan

↳ 20090618140613.xml.gz

The XML file contains the data of all measurements since the previous upload. The data is gzip compressed.

8.1 XML file structure

The XML structure is described as follows. It represents a data table consisting of a description of column and following data lines.

8.1.1 Section <description>

The characteristics of the individual data columns are defined within the range <description> of the XML files.

Attribute	Description
col_ref	Column name = identification for data base reference (see chapter 8.1.1.1).
dict_ref	Continuing identification, reserved for future extensions; Entries are currently identical to col_ref.
data_type	Definition of data type (see chapter 8.1.1.2).
unit	Applied SI-unit (e.g.: °C, V, W/m ²).
data_size	Data size in byte (e.g.: 2, 4, 32, 2048), from where the maximum number of digits in numeric data can be determined.
data_precision	Definition of decimal places (granularity), usually equivalent to the metering precision (e.g.: 1, 0.01, 0.001).

8.1.1.1 Description of column name (col_ref)

The declaration for col_ref determines the column heading in the data base table and thus the names of the related measuring data.

Following measuring data is available for SOL.Connect Center:

col_ref	Example
timestamp	Timestamp of the measurement start time. Contains of date and start time of the minute-by-minute measuring cycle.
inverter_id	Internal reference number of the IV characteristic data logger (= measuring station) for administrative purposes: timestamp and inverter_id combined result in an unique measuring data set key.
serialnumber	Serial number of I-V-characteristic data logger.
...	Depending on the connected inverter manufacturer. Measurement equal to investment status (see Policy Manual of the inverter manufacturer)

8.1.1.2 Data type (`data_type`)

The data type defines the structure of information. This is important for the data base structure.

<code>data_type</code>	Description
T	Timestamp: contains starting date and time of measuring cycle.
C	Controller: serial number of ISET-mpp meter measuring card
S	String: text with limited length of <code>data_size</code>
I	Integer: signed integer
J	Natural number
R	Real: signed fixed-point value

8.1.2 Section `<row>`

For each data line exists a section `<row>` in the XML file, wherein again the data elements are contained of column for each as `<item>`.

8.2 XML file example

A XML file is separated into header, declaration and data.

```

1  <?xml version="1.0" encoding="ISO-8859-1" ?>
2  <!DOCTYPE sccdata [
3  <!ENTITY amp "#38;">
4  <!ENTITY auml "#228;">
5  <!ENTITY ouml "#246;">
6  <!ENTITY uuml "#252;">
7  <!ENTITY Auml "#196;">
8  <!ENTITY Ouml "#214;">
9  <!ENTITY Uuml "#220;">
10 <!ENTITY szlig "#223;">
11 <!ENTITY lt "#60;">
12 <!ENTITY gt "#62;">
13 <!ENTITY quot "#34;">
14 <!ELEMENT sccdata (description,row*)>
15 <!ELEMENT description (column*)>
16 <!ELEMENT column (#PCDATA)>
17 <!--
18 <!--
19 <!--
20 <!--
21 <!--
22 <!--
23 <!--
24 <!--
25 <!--
26 <!--
27 <!--
28 <!--
29 <!--
30 <!--
31 ]>

```

Image 8-1 Header of XML file

```

<?xml version="1.0" encoding="ISO-8859-1" ?>
- <sccdata>
- <description>
  <column col_ref="timestamp" dict_ref="timestamp" data_type="T" unit="" data_size="4" data_precision="1" />
  <column col_ref="inverter_id" dict_ref="inverter_id" data_type="J" unit="" data_size="4" data_precision="1" />
  <column col_ref="serialnumber" dict_ref="serialnumber" data_type="C" unit="" data_size="32" data_precision="1" />
  <column col_ref="vac_1" dict_ref="vac_1" data_type="J" unit="V" data_size="4" data_precision="1" />
  <column col_ref="iac_1" dict_ref="iac_1" data_type="J" unit="A" data_size="4" data_precision="0.001" />
  <column col_ref="vac_2" dict_ref="vac_2" data_type="J" unit="V" data_size="4" data_precision="1" />
  <column col_ref="iac_2" dict_ref="iac_2" data_type="J" unit="A" data_size="4" data_precision="0.001" />
  <column col_ref="vac_3" dict_ref="vac_3" data_type="J" unit="V" data_size="4" data_precision="1" />
  <column col_ref="iac_3" dict_ref="iac_3" data_type="J" unit="A" data_size="4" data_precision="0.001" />
  <column col_ref="pac" dict_ref="pac" data_type="J" unit="W" data_size="4" data_precision="1" />
  <column col_ref="day_yield" dict_ref="day_yield" data_type="J" unit="kWh" data_size="4" data_precision="0.001" />
  <column col_ref="fac" dict_ref="fac" data_type="J" unit="Hz" data_size="4" data_precision="0.01" />
  <column col_ref="vdc_1" dict_ref="vdc_1" data_type="J" unit="V" data_size="4" data_precision="0.1" />
  <column col_ref="idc_1" dict_ref="idc_1" data_type="J" unit="A" data_size="4" data_precision="0.001" />
  <column col_ref="vdc_2" dict_ref="vdc_2" data_type="J" unit="V" data_size="4" data_precision="0.1" />
  <column col_ref="idc_2" dict_ref="idc_2" data_type="J" unit="A" data_size="4" data_precision="0.001" />
  <column col_ref="vdc_3" dict_ref="vdc_3" data_type="J" unit="V" data_size="4" data_precision="0.1" />
  <column col_ref="idc_3" dict_ref="idc_3" data_type="J" unit="A" data_size="4" data_precision="0.001" />
  <column col_ref="tinvt" dict_ref="tinvt" data_type="J" unit="C" data_size="4" data_precision="0.1" />
  <column col_ref="riso" dict_ref="riso" data_type="J" unit="kOhm" data_size="4" data_precision="1" />
  <column col_ref="status" dict_ref="status" data_type="S" unit="" data_size="16" data_precision="1" />
  <column col_ref="error" dict_ref="error" data_type="S" unit="" data_size="16" data_precision="1" />
  <column col_ref="plimit" dict_ref="plimit" data_type="J" unit="W" data_size="4" data_precision="1" />
  <column col_ref="phase" dict_ref="phase" data_type="J" unit="" data_size="4" data_precision="1" />
  <column col_ref="cosphi" dict_ref="cosphi" data_type="T" unit="" data_size="4" data_precision="0.001" />

```

Image 8-2 Declaration of XML file

9 Disposal

Disposal of Waste Equipment by Users in Private Households in the European Union:



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

SOL.Connect Center







10 Technical Data

SOL.Connect Center	
Processor	Industrial PC, CPU AMD SC520, 133 MHz, Flash BIOS, 64 MB RAM, RTC
Main Memory	64 MB RAM
Operating System	Linux
COM Ports	1x RS485 on terminal strip 1x RS485 RJ45 double socket
Interfaces	LAN (Ethernet 10/100 full-duplex) Modem or GSM connection SUB-D9 EasyLan
Signals	Internal loudspeaker LEDs for indicating events (6 green, 2 red), 3 LEDs on the multipoint connector
Data Storage	Compact Flash [®] type I adapter inside the housing for operating system and data storage
Housing	2-part, non-ventilated metal housing for carrier-rail mounting (IP20)
Weight	800g net (without accessories and cable)
Environment humidity	Indoors/Switch cabinet
Operating Temperature	Minimum 0 ... +50°C
Dimensions	175 mm x 155 mm x 45 mm (W x H x D) including rear carrier rail adapter and multipoint connector
Alarm Contact	Potential-free Out-put max. 48VDC
Electricity Supply	12-24 VDC power supply: typically 5-7 W via an external plug-in power supply unit




11 Symbol definition

By moving the mouse over the individual symbols a description will be shown as "tool tip".

11.1 General

Symbol	Description
	New column
	Delete column
	Change settings
	Scroll forward
	Scroll back
	Deactivate

11.2 Status display

Symbol	Description
	Green: plant running normally
	Yellow: an inverter has recognised a failure (no communication, no contribution to network).
	Red: at least 30% of the inverters have recognised a failure (no communication, no network supply).

11.3 Notification

Symbol	Description
	Activate alarm
	Deactivate alarm

12 Declarations of Conformity

Competence in Software Services - Consulting, Development and Support



CE-Declaration of conformity

The manufacturer Papendorf Software Engineering GmbH
Robert-Bosch-Str. 10
D-71116 Gärtringen

certifies, that the products of the product line

SOL.Connect® Center

correspond to the requirements set by EC Directive 2004/108/EG as well as Directive 73/23/EWG, revised by Directive 93/68/EWG.

For conformity evaluations, the following harmonised standards are consulted:

- EMV- Directive:
- EN 61000-6-2, with the basic standards listed therein (Immunity for industrial environments)
 - EN 61000-6-3, with the basic standards listed therein (Emission standard for residential, commercial and light industrial environments)
- Low voltage- Directive:
- EN 61010-1 (safety regulations for electrical measuring instruments, control instruments and laboratory equipment – Part 1: General requirements)



The CE mark certifies conformity with the above-mentioned standards and policies.

Gärtringen, May 2008


Peter Papendorf, Managing Director

RoHS-Declaration of Conformity

The manufacturer Papendorf Software Engineering GmbH
Robert-Bosch-Str. 10
D-71116 Gärtringen

certifies that all used products of product line

SOL.Connect® Center

correspond to the requirements of the RoHS guideline 2002/96/EG
(27.01.2003) from the

01.07.2006

and contains none of the restricted substances in concentrations higher than
the upper limit. The RoHS guideline stipulates the enforcement for Restriction
of Certain Hazardous Substances in Electrical and Electronic Equipment
Regulations.

Gärtringen, January 2007


Peter Papendorf, Managing Director

13 Image index

Image 3-1 Standard system overview	9
Image 4-1 SOL.Connect Center connections	14
Image 5-1 IP (in delivery status) entry into web browser	20
Image 5-2 LAN connection properties	20
Image 5-3 TCP / IP connection properties	21
Image 5-4 Display connection	25
Image 6-1 Wall bracket	27
Image 7-1 User authentication	29
Image 7-2 Start page.....	30
Image 7-3 Plant state - inverter	32
Image 7-4 Plant state - inverter status	33
Image 7-5 Overview of monitoring.....	34
Image 7-6 Monitoring protocol	35
Image 7-7 Configuration monitoring settings.....	36
Image 7-8 Activated alarm	39
Image 7-9 Overview of evaluations	40
Image 7-10 Report navigation protocol.....	41
Image 7-11 Report event protocol	41
Image 7-12 System information	45
Image 7-13 Network configuration	47
Image 7-14 Modem configuration	48
Image 7-15 Editing the start page	51
Image 7-16 System time configuration	52
Image 7-17 Configuration system language.....	55
Image 7-18 Configuration of mail service.....	56
Image 7-19 Message recipient - Email	60
Image 7-20 Message recipient – alarm contact	62
Image 7-21 Message recipient - SOL.Connect Portal.....	63
Image 7-22 Notification for message recipient	64
Image 7-23 SOL.Connect Portal – sensor data	65
Image 7-24 Solar plant	67

Image 7-25 Inverter search	69
Image 7-26 Inverter configuration	70
Image 7-27 Search sensor modules	71
Image 7-28 Sensor modules	72
Image 7-29 Input configuration	74
Image 7-30 Output configuration	75
Image 7-31 Reimbursement according to German EEG Novelle	76
Image 7-32 Self defined reimbursement model.....	77
Image 7-33 Administration of group of inverter	78
Image 7-34 Public access	80
Image 7-35 Passwords	81
Image 7-36 Download overview.....	82
Image 7-37 Download formula side	83